

Fresh Aero EasyBrow Dimmer Notes

Drill a 3/8 inch hole and mount this dimmer in a convenient location on your upper instrument panel or on your lower eye brow. A step drill or a series of pilot drills work well for this application. Be sure to check for proper clearance behind the panel.

Cut the negative (white) LED lead and connect the dimmer wire leads in series with this lead. This configuration puts the dimmer at ground potential. Use the crimp butt terminals to connect the leads. Crimp tightly and confirm a secure connection.