

## **Installing the Fresh Aero Stainless Steel Eyebolts on Grumman AA-1 and AA-5 Aircraft**

This is a very simple procedure! Just insert a long shank screwdriver (or similar metal rod or pipe) through the existing eyebolt holes and turn the eyebolts counterclockwise to remove them. Install your new stainless steel eyebolts using the same procedure. Use care not to abrade your aircraft with the screwdriver. Use the included nylon washers as spacers to align the eyebolts.

The wingtips or tail cone do not need to be removed to install these eyebolts. This would only be necessary if the original eyebolts corroded and fused to the attach nuts on the airframe – very rare.

Enjoy your new Fresh Aero Stainless Steel Tiedown Eyebolts!

Fresh Aero Aviation, 1142 Roseland Drive, Columbia, TN 38401-7700  
Phone: 931 381 6092, Email: [info@freshaero.com](mailto:info@freshaero.com)  
[www.freshaero.com](http://www.freshaero.com)